



Remote User Guide: Clientless

Step 1 – Login to the PCD Greendoor remote access platform


1. Open your preferred browser:





2. Access the GateManager at:
<https://greendoor.heiway.net/lm>

3. Select **"Authenticate with Microsoft"** and press **"Login"**




- You are now redirected to [Microsoft Azure Single Sign-On](#)
- Login with your credentials.




Step 2 – Find your equipment > Request Access>Start working



- When logged into the platform you will see the equipment listed by location, and you can request access.
- Select the equipment you need access to, click **"Request Access"** – put in a comment if needed.




- A popup will appear and show you to whom the request has been sent.
- When connection is approved, a popup will notify you and the button will change to **"Connect"** and you will also be able to use the **clientless** connection options through the **"WWW"**, **"VNC"** and **"RDP"** buttons.



The available buttons will differ depending on the device you are trying to access.

- "Connect"** button is used for the LinkManager direct tunneling (see [Remote User Guide Client](#))
- "VNC"** button is used for VNC, either in-browser or external VNC e.g., UltraVNC or TightVNC.
- "RDP"** button is used for Remote Desktop using external programs e.g., Windows Remote Desktop.
- "WWW"** button is used for webpages by opening a new tab in the browser.

Configuration of the VNC and RDP buttons can be configured with by pressing the lightbulb icon.



Press the **button** for your desired connection type and start your work.